




# Typical Pushbutton Head



# Landing Gear Indicator



Connect +12Volts to the top of the LEDs, and to light each LED(s) pull the resistor(s) to GND

NOTE \*\*\*\* The RUSCOOL 64Output board has electronic switches that pull the resistor(s) to Ground